

Changing the pencil lead

1. Twist the pencil mechanism clockwise all the way until the lead is fully extended and falls out. This will also clear out any broken pieces of lead that can jam the mechanism.
2. Twist the mechanism counter clockwise until the extension is about 3mm outside of the threaded end of the mechanism.
3. Insert the new lead into the hole.
4. Continue to turn the mechanism counter clockwise drawing the lead up into the mechanism.
5. For extra leads pull out the eraser assembly on the top of the mechanism to access the spare leads.

